HUWOR · ZHUHAI HUAWANG TECHNOLOGY CO., LTD.

GIS & SF6 Monitoring Guide for Middle East Substations

UHF partial discharge monitoring and SF6 density / decomposition management for Gulf utilities

Technical White Paper · 2026
www.huwor.net · hezhiqiang@huwor.com.cn

Contents

1. GIS and SF6: The Backbone of GCC Transmission
2. Why Online PD Monitoring Is a Priority in the Gulf
3. UHF Partial Discharge Monitoring Fundamentals
4. SF6 Monitoring: Density, Moisture and Decomposition
5. Integrating PD and SF6 Data
6. Deployment Roadmap for Gulf Substations
7. Designing for Desert Conditions
8. HUWOR Solutions Overview
9. Getting Started

> This guide is written for transmission asset managers, maintenance engineers and consultants working with GIS-based substations across Saudi Arabia, the UAE, Qatar, Kuwait, Oman and Bahrain.

1. GIS and SF6: The Backbone of GCC Transmission

Gas-insulated switchgear (GIS) dominates new substation construction across the Gulf. Its compact footprint suits dense urban networks and desert terrain, and its sealed SF6 insulation offers excellent dielectric performance. But the same sealed design that makes GIS compact also makes internal faults invisible until they escalate — a reality that has driven Gulf utilities to lead the region's adoption of online condition monitoring.

2. Why Online PD Monitoring Is a Priority in the Gulf

GIS-heavy
sealed SF6 compartments make internal defects invisible

>50 °C
summer ambient temperatures stress insulation systems

Zero-tolerance
reliability culture drives condition-based maintenance

Four factors combine to make online partial discharge monitoring a high priority:

- **GIS concentration:** sealed compartments cannot be inspected visually; electronic monitoring is the only continuous window into insulation health.
- **Thermal cycling:** extreme day–night and seasonal temperature swings promote void growth in spacers and insulators — a primary source of internal discharge.
- **Renewable integration:** NEOM, solar parks and new industrial cities add switching stress to existing grids; new connections demand proof of switchgear health.
- **Reliability culture:** Gulf utilities benchmark against world-class indicators and invest where outage risk is reduced fastest.

3. UHF Partial Discharge Monitoring Fundamentals

3.1 The UHF Principle

Partial discharge inside GIS radiates electromagnetic energy in the UHF band (300 MHz–3 GHz). This energy escapes the metal enclosure at dielectric apertures — spacer insulators, inspection ports and cable sealing ends — where a UHF sensor can capture it with pC-level sensitivity, without opening the compartment and without an outage.

3.2 Sensor Types

Type	Installation	Best Use
Internal couplers	Built into GIS at manufacture	New build, maximum sensitivity

External sensors	Retrofitted at spacer apertures	Existing substations
Portable UHF instruments	Temporary placement	Baseline surveys, verification

3.3 Sensor Placement

Sensors are placed at each busbar section and at disconnector and breaker compartments — the historically highest defect locations. A typical 132–400 kV GIS bay uses 4–8 sensors. For existing GIS, verify spacer aperture availability before specifying the sensor count.

4. SF6 Monitoring: Density, Moisture and Decomposition

SF6 is both the insulation medium and a potent greenhouse gas. Managing it properly is a compliance requirement and a maintenance tool.

Parameter	What It Reveals	Typical Interval
Gas density	Leaks and pressure integrity	Continuous / daily
Dew point (moisture)	Water ingress, insulation health	Quarterly – annually
Decomposition products (SO2, HF)	Active discharge or arcing	Continuous on monitored bays
Purity	Gas quality for refill decisions	Annually

Why Decomposition Monitoring Matters

When a discharge or arc occurs inside an SF6 compartment, the gas breaks down into sulfur compounds including SO2 and hydrogen fluoride (HF) — corrosive to internal components and hazardous to personnel. Detecting their rise in real time gives early warning of developing faults, seen from the gas side, complementing UHF detection from the electromagnetic side.

5. Integrating PD and SF6 Data

The most effective Gulf programs run UHF partial discharge monitoring alongside SF6 density and decomposition monitoring, integrated into a single platform:

- A rise in SF6 decomposition products is cross-checked against UHF trends to confirm and localize the fault.
- Density data supports leak-rate analytics and SF6 emission reporting.
- Alarms are prioritized by asset criticality and defect confidence, not raw sensitivity.

6. Deployment Roadmap for Gulf Substations

Phase 1 — Engineering Survey (weeks 1–2)

Map GIS bay layouts, identify spacer apertures, confirm sensor count per bay, and verify environmental ratings for outdoor installations.

Phase 2 — Pilot Bay Installation (weeks 3–8)

Install sensors on one critical bay with a monitoring unit and cloud access. Run 4–8 weeks to establish local baseline levels and validate alarm settings.

Phase 3 — Fleet Expansion (months 2–6)

Roll out to priority substations, aggregate into one platform, and train local engineers on trend review and alarm response.

7. Designing for Desert Conditions

- **Ambient temperature:** sensors and enclosures must tolerate sustained 50 °C+ outdoor conditions.
- **Sand and dust:** outdoor housings need IP-rated sealed enclosures with no exposed optics.
- **Solar loading:** mounting and enclosure selection should account for direct sun exposure.
- **Protocol integration:** outputs should support Modbus and IEC 61850 options for SCADA connection.
- **Spare strategy:** plan for hot-spare sensors to keep monitoring continuity during maintenance.

8. HUWOR Solutions Overview

Product Family	Description	Typical Use
Built-in UHF PD Sensors	Permanent UHF couplers for GIS apertures	GIS online monitoring
SF6 Monitoring	Density, dew point and decomposition (SO2/HF) measurement	GIS compartment management
Handheld PD Detector	TEV + HFCT + AE, IEC 60270 based	Commissioning, verification, troubleshooting
IoT Gateway + Cloud Platform	Data aggregation, dashboards, alarms, SCADA integration	Fleet-wide online monitoring
Surge Arrester Monitoring	Leakage current and counter monitoring	Arrester health tracking

All HUWOR products support OEM/ODM customization — product specifications, branding, software platforms and packaging — for utilities standardizing on their own requirements.

9. Getting Started

1. Survey one pilot substation and identify critical bays.
2. Install UHF sensors and SF6 monitoring on 2–4 pilot bays.
3. Run 4–8 weeks of baseline data collection.
4. Validate alarms and trend review processes with local engineers.
5. Build the fleet expansion business case from pilot evidence.

HUWOR supports every step — instruments, sensors, platform, training and remote diagnostics. For a deployment discussion, contact our export team.

HUWOR · Zhuhai Huawang Technology Co., Ltd. · www.huwor.net · hezhiqiang@huwor.com.cn · +86-13680390857
Zhuhai (HQ) & Xi'an R&D centers · High-voltage monitoring solutions since 2010